# **How to Install Silver Rail Fencing**

Thank you for choosing Jacksons Fencing. Our high quality fencing products will last for years and give you trouble-free service if you follow the installation instructions below, which are offered as a general guide.

## **Tool**

String line	Post level		Clawhammer	Post driv	er Maul	Spade/shuvholer	
Tape measure	Saw	Pencil	Marke	er pegs	Rammer	Peeler bar	

# **Materials**

You will need the correct quantity of intermediate, corner and end posts, plus galvanized rails. It is advisable to allow for two posts and changes in direction, rather than 90 degree corners.

#### PLEASE READ THESE NOTES BEFORE STARTING WORK

All Timber Posts installation require proper drainage to avoid premature rotting. For Detail refer to the installation instruction for "Timber Fence Post".

## Method

12)

- 1) Clear and level the site.
- 2) Establish ends, corner positions and changes of direction, and mark with pegs.
- 3) Each section of fence will be built in turn. For example: from the beginning to the first change of direction; the first change of direction to the second, and so on.
- 4) To establish the line for the first length of fence, you will need to put in the first post and the last post, so these can be used as sighting posts. If it is a very long section of fence, you may prefer to work in shorter straight sections.
- 5) Dig the hole for the first post with vertical sides, making the hole as small as practical to allow for refilling and ramming.
- 6) Place the first post in the hole, allowing enough of it above ground to suit the height and style of fence.
- 7)
  Replace excavated soil a bit at a time, ramming in well as filling proceeds. If the ground conditions are very soft, it is advisable to set the posts in a weak concrete mix. Use the spirit level to make sure it is upright, and ram in firm.
  - Infill the second post as above. You will be able to sight across the first post and the last post to ensure the second post is at the correct height. If the ground is undulating, the fence should follow the contours of the ground. Install the rail as the installation commences.
- Fix the string line between the first and last post and pull taut. The string line should be about 750mm above ground. It is easier to place the posts in line if the string is 50mm away from the edge of the post.
- Mark out the post centres along the section (according to the style of fence being installed). Make a small hole with the peeler bar to mark the post centres. You may have to have a short bay next to the last post. Only dig a few holes at a time, otherwise you may make a cumulative error.
- 11)
  Move the string line out of the way, and dig out the holes to the correct size and depth. Then replace the string line.
  - If the fence post needs lowering, the hole will need digging out a bit deeper, or you may be able to knock the post in if it only requires to go down a small amount. This can be done by using the side of a sledgehammer or maul. If the post needs raising, some of the excavated soil will need to be put back and rammed tight. This can be done by using

Jacksons Fencing Head Office Stowting Common Ashford Kent TN25 6BN Tel +44 (0) 1233 750393 Fax +44 (0) 1233 750403 www.jacksons-fencing.co.uk



13) the post itself as a rammer.

When the post is at the correct height and in line with the string line, it can be backfilled and rammed as above.

14)

Plant the third post as in paragraph 6, and pass the rail through the posts, ensuring the rail end and joiner are positioned halfway through the post.

15)

Repeat paragraphs 8 - 13 until the fence run is completed.

16)

Tidy up the site, making sure no nails have been left laying around in case they cause injury to children or animals.

17)

Treat all ends with Cut & Treat, and any cut galvanizing with the "touch-up" paint supplied.

# **Safety Notes:**

Biocidal Products Regulation (EU528/2012):

Jakcured articles incorporate biocidal products to protect against wood destroying organisms.

Active ingredients include: Copper(II)Carbonate / Copper(II)Hydroxide / Propiconazole / Tebuconazole

Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting. Dispose of off-cuts responsibly – do not burn.

Jacksons Fencing Head Office Stowting Common Ashford Kent TN25 6BN Tel +44 (0) 1233 750393 Fax +44 (0) 1233 750403 www.jacksons-fencing.co.uk

