

How to Install Viper-Spike

Thank you for choosing Jacksons Fencing. Our high quality fencing products will last for years and give you trouble-free service if you follow the installation instructions below, which are offered as a general guide.

Tools (dependant on fixing method)

| | | |
|------------------------|-----------------------|-------------------------|
| Suitable tape measure. | Battery drill | Selection of drill bits |
| Tek screw driver | Selection of spanners | |

Materials

| | | | |
|--------------|-------------|------------|-----------------|
| Coach screws | Tech screws | Rawl plugs | Zinc rich paint |
|--------------|-------------|------------|-----------------|

Viper-Spike may be fitted either to existing fencing or the top of a wall, and need fixings to suit application.

- 1) Measure and cut any Viper-Spike before fitting, taking care to seal cut ends with a suitable zinc rich paint.
- 2) Carefully mark through the existing holes in the Viper-Spike.
- 3) Drill masonry using a suitable size and appropriate drill.
- 4) Fit rawl plugs.
- 5) Fix using suitable coach bolts (usually M8).
- 6) Alternatively fit in place using tek screws and special driver bit.

Note:

This type of security device must not be hidden from view. We recommend 'Danger Signs' are used every 8-10 metres and at changes of direction along any run of security topping.