

## How to Install Cobra-Spike

Thank you for choosing Jacksons Fencing. Our high quality fencing products will last for years and give you trouble-free service if you follow the installation instructions below, which are offered as a general guide.

### Tools (dependant on fixing method)

Suitable tape measure.	Battery drill	Selection of drill bits
Tek screw driver	Selection of spanners	

### Materials

Coach screws	Tech screws	Rawl plugs	Zinc rich paint
--------------	-------------	------------	-----------------

Cobra-Spike may be fitted either to existing fencing or the top of a wall, and need fixings to suit application.

- 1) Measure and cut any Cobra-Spike before fitting, taking care to seal cut ends with a suitable zinc rich paint, and touch up if powder coated.
- 2) Carefully mark through the existing fixing holes in the Cobra-Spike.
- 3) Drill masonry using a suitable size and appropriate drill.
- 4) Fit rawl plugs.
- 5) Fix using suitable coach bolts (usually M8).
- 6) Alternatively fit in place using tek screws and special driver bit.

### Note:

This type of security device must not be hidden from view. We recommend 'Danger Signs' are used every 8-10 metres and at changes of direction along any run of security topping.