Customer Name: Sales Order No: Salesman: Jacksons Fencing DO NOT SCALE - IF IN DOUBT ASK Manufacture Tolerance +/-5mm Note: Please complete all the steps and fill in all the required measurements. In case of any queries contact your salesperson.			GATE HANDING & OPENING: The handing of the gate is determined by the position of hinges when the gate is viewed from outside. Hinges are always on the opening side of the Gate. *Step 4: Please tick appropriate box for desired Gate Fitting option. OPTION 1: UNFITTED GATE(s)
*Step: 2 "Actual Gate Width" Measurement Remember it is 20mm less than the "Width Between Posts". Ground Level	Actual Gate Height Total Gate Height Total Gate Height Not including 50mm ground clearance	*Step: 3 Total Gate Height" lluding Capping Rail Measurement emember not to include 50mm for Ground Clearance. EACH GATE LEAF SIZE LIMITATION	*Special Trellis Gates can be supplied unfitted but must be installed with our "L" shape hinges. Other hinge types will not prevent the gate frame dropping. OR OPTION 2: FITTED GATE(s) Please tick appropriate Box for desired Gate hanging & opening. a. Standard Right Hand Hang Opening Inwards Hinge Position Hinge Position INSIDE
*Step:1 "Width between Posts" Measurement Wiewed From Outside GATE SHOWN RIGHT HAND HANGING STANDARD CONFIGURA For your requirements select the appropriate of the steps are completed and information is filled case of any queries contact your salesperson. Stowting Common, Near Ashford, KENT. TN25 6BN Telephone: 01233 750393	m. Before returning in and checked. In DATE: ITEM: SPECIAL STANDARD	Max Actual Gate Height (mm) Allowable Actual Gate Width (mm) 1750 1000	c. Right Hand Hang Opening Outwards INSIDE Hinge Position d. Left Hand Hang Opening Outwards
Fine: 01233 750403 (2) 23-08-2 (1) 11-01-2	2011 Template Changed Charles DD	Drawing No. J7/02137 Rev4 Sheet 1 of 4	Hinge Position